



Cisco SPA100 Series Analog Telephone Adapter

Account Setup

Publication History

Date	Version	Author
===== August 24th, 2017	===== 1	===== Jeffrey K Brady

2000-2017 Ironton Telephone Co

Proprietary

© All rights reserved.

Information subject to change without notice.

The information disclosed herein is proprietary to Ironton Telephone Company or others and is not to be used by or disclosed to unauthorized persons without the written consent of Ironton Telephone Company. The recipient of this document shall respect the security status of the information.

Cisco SPA100 Series Analog Telephone Adapters:


1. Access the Sip Device's IP Address.

- A. Using for a Fax machine.
 - I. Connect an analog phone to the phone port of the ATA.
- B. Accessing the Analog Terminal Adapters IVR.
 - I. Press the star key four times: ********
 - a. The greeting plays.
- C. Enter Code.
 - I. Press 100.
 - II. Press the # (pound) key to indicate that you have finished entering the code.
 - a. The IP address will be announced.



2. Accessing the Web Interface.

- A. Enter the IP address into the web browser address bar.
- B. The Login screen will appear.
 - I. Enter the Username in the text field.
 - II. Enter the Password in the text field.
 - III. Select the Login button.



- C. The Quick Setup Screen will open.



- D. Enter the following information for the Account in the text boxes.
 - I. Proxy:
 - a. sip.itcgn.com
 - II. Display Name:
 - The local name showing showing on other SIP devices when called within the switch.
 - a. Options.
 - 01. Phone number.
 - 02. Users Name.
 - 03. and / or Extension Number.
 - III. User ID
 - The Account ID provided in the Welcome Letter.
 - 11 Digit Phone number.
 - IV. Password:
 - a. The Service Password provided in the Welcome Letter.
- E. Select the Submit button at the bottom of the page when finished.
 - I. Select the Cancel button to cancel entries.

